



## AVB, MY DEVICE CABLE + INTEGRATION

- SUITE AVB (SHOWN ABOVE) BACK PORTS, from left to right:
  - Green: Not in use
  - Fiber Port: for Video communication between AVB & System Rack
  - Audio Input: For My Device
  - HDMI Input: For DVD player
  - Audio Out: For Patient Audio System, if applicable & integrated
  - HDMI Out: For Desk Display
  - 19VDC: For Power cable
  - AVB FRONT PORTS: Available for charging devices
- INTEGRATING CARING SUITE AUDIO WITH MRIDIAN PATIENT AUDIO SYSTEM:
  - Connect a 3.5mm to 2-Male RCA audio cable from the PDC AVB "Audio Out" port to the MRIdian Central Intercom Unit "CV in" RCA ports
- AVB 2: A 2nd AVB connects to the ViewRay computer