



TECHNOLOGIST PORTAL + CUSTOM START SCAN + PATIENT PREP

- **TAP LIGHT CONTROL** & tap "Profile Editor" at top of the Light Control panel to customize "Start Scan" & "Patient Prep" One-Touch Controls
- **CHOOSE THE PROFILE TO EDIT** by tapping "Start Scan" or "Patient Prep" below "Light Profiles" menu at left
- **ADJUST LIGHTING** to preference using sliders below "Light Zone Levels." If you wish to set lighting zones to different levels, tap the blue link below the zone, ensure link is gray & broken, & set light to desired level. Lighting will reflect live in your suite. Ensure "Can Lights" remains linked
- **TAP SAVE** icon when complete beside all sliders & beside "Light Zone Levels"