



FULL-LENGTH PRIVACY GLASS RF DOOR AND VIEWING WINDOW

EASILY TOGGLES BETWEEN CLEAR AND OPAQUE FOR PATIENT PRIVACY AND SAFETY!

- Effortless to open and close
- No inflatable bladders or RF fingers
- Safety - all PDC Semi-Automatic and Automatic RF Doors can be opened manually using the door handle anytime
- PDC's RF gasket material resists oxidation, reduces sound transmission and eliminates premature failures associated with other types of RF sealing material
- Semi-Automatic RF Door systems ensure uniform EMI seals around the RF door and frame
- Meets or exceeds all MR manufacturers' attenuation specifications
- Equipped with two push-plate door actuators and a key activated power switch for locking and securing room
- Door finish can be selected by the customer
- RF Privacy Glass in the door can be full glass or partial glass as selected by the customer
- Privacy Glass is also available for MRI RF Viewing Windows

SEE OUR DOOR IN ACTION!



RF GLASS DOOR WITH PRIVACY VIDEOS

Scan QR code with cell phone or if viewing on computer - mouse over and click on QR code



pdcbiz.com • For additional information email pdcbiz@pdcbiz.com



MRI DOOR FRAME IV WAVEGUIDE

- Eliminates disconnecting and then reconnecting critical IV lines and medical tubing by routing through the open waveguide that is closed to assure RF attenuation
- Non-MR compatible devices remain outside the scan room while connected to the patient and routed through the MRI Door Frame IV Waveguide
- Allows patient transport and positioning on the MR table to be accomplished with minimal medical intervention



The MRI Door Frame IV Waveguide is an optional feature that can be added to the frame during manufacturing. IV Waveguides cannot be retrofit to a frame after the frame has been manufactured.

WAVEGUIDE VIDEO

Scan QR code with cell phone or if viewing on computer - mouse over and click on QR code



PDC SEMI-AUTOMATIC AND AUTOMATIC RF DOORS

- Equipped with push-plate actuators located both inside and outside the MR scan room allowing automatic entry and exit at all times
- RF Doors can also be opened using the door lever handle at all times, unless intentionally locked for security purposes
- Push-plate door actuators are equipped with a power off key to disable the automatic system for security purposes
- Fully Automatic RF Doors are available without Privacy Glass option

SEMI-AUTOMATIC DOOR VIDEO

Scan QR code with cell phone or if viewing on computer - mouse over and click on QR code



PDC's Full-Length Privacy Glass RF Doors are completely customizable.

Contact PDC today to discover what PDC's door can do to improve outcomes in your facility!